



# **RIVA RACING**

**PERFORMANCE PRODUCTS & ACCESSORIES**

## **Sea-Doo Top-Loader Intake Grate**

**PART# - RS22050 / 055 / 060 / 080**

**APPLICATION(S):** Sea-Doo RXP-X, RXT-X, RXP, RXT, GTX(all), GTI(4-TEC)

1. Remove stock intake grate. **NOTE: If bolts are difficult to remove apply heat.**
2. Clean hull and supplied intake grate with a non-residual cleaner.
3. Install intake grate and secure using stock hardware. **NOTE: Apply blue Loc-tite to bolts. Torque front bolt to 26 N•m (19 lbf•ft) and three rear bolts to 11 N•m (97 lbf•in).**

### **Technical Support**

For answers to questions regarding installation or trouble shooting RIVA Performance Products contact:  
RIVA Technical Support directly at (954) 247-0705 or by e-mail at [tech\\_support@rivamotorsports.com](mailto:tech_support@rivamotorsports.com).



# **RIVA RACING**

**PERFORMANCE PRODUCTS & ACCESSORIES**

## **Sea-Doo Top-Loader Intake Grate**

**PART# - RS22050 / 055 / 060 / 080**

**APPLICATION(S):** Sea-Doo RXP-X, RXT-X, RXP, RXT, GTX(all), GTI(4-TEC)

1. Remove stock intake grate. **NOTE: If bolts are difficult to remove apply heat.**
2. Clean hull and supplied intake grate with a non-residual cleaner.
3. Install intake grate and secure using stock hardware. **NOTE: Apply blue Loc-tite to bolts. Torque front bolt to 26 N•m (19 lbf•ft) and three rear bolts to 11 N•m (97 lbf•in).**

### **Technical Support**

For answers to questions regarding installation or trouble shooting RIVA Performance Products contact:  
RIVA Technical Support directly at (954) 247-0705 or by e-mail at [tech\\_support@rivamotorsports.com](mailto:tech_support@rivamotorsports.com).



# **RIVA RACING**

**PERFORMANCE PRODUCTS & ACCESSORIES**

## **Sea-Doo Top-Loader Intake Grate**

**PART# - RS22050 / 055 / 060 / 080**

**APPLICATION(S):** Sea-Doo RXP-X, RXT-X, RXP, RXT, GTX(all), GTI(4-TEC)

1. Remove stock intake grate. **NOTE: If bolts are difficult to remove apply heat.**
2. Clean hull and supplied intake grate with a non-residual cleaner.
3. Install intake grate and secure using stock hardware. **NOTE: Apply blue Loc-tite to bolts. Torque front bolt to 26 N•m (19 lbf•ft) and three rear bolts to 11 N•m (97 lbf•in).**

### **Technical Support**

For answers to questions regarding installation or trouble shooting RIVA Performance Products contact:  
RIVA Technical Support directly at (954) 247-0705 or by e-mail at [tech\\_support@rivamotorsports.com](mailto:tech_support@rivamotorsports.com).