



Quick-turn Steering Nozzle INSTALLATION INSTRUCTIONS

Note: If unsure of location and removal procedures, consult your Yamaha water vehicle's service manual.

1. Disconnect negative and positive leads from battery. Turn fuel off.
2. Detach steering cable joint from stock steering nozzle by first removing lock nut and washer. Then remove steering cable joint from stock steering nozzle. **NOTE:** Retain lock nut and washer.
3. Remove stock steering nozzle from nozzle ring by removing the two M8x20 bolts, washers and collars. **NOTE:** Retain bolts, washers and collars.
4. Install RIVA Quick-turn steering nozzle onto nozzle ring using the two original M8 bolts, washers and collars.* **NOTE:** Apply Loctite 271 onto threads of each bolt. Torque to 16 Nm (1.6 m • kg, 11 ft • lb).
***=FOR GPR Applications use the two provided M8x16 socket head cap bolts.**
5. Install steering cable joint to RIVA Quick-turn steering nozzle. Secure using retained OE lock nut and washer. **NOTE:** Apply Loctite 271 to threads on steering cable joint.
NOTE: There are two steering cable joint hole options. Quick-Steer (inner hole) and Standard steering (outer hole). **GP760 and GP1200 applications must use outer steering cable joint hole only. Use of inner steering cable joint hole will result in steering cable damage.**
6. Check steering movement for any binding. It may be necessary on some water vehicles to adjust steering cable joint on steering cable to center Quick-turn nozzle.
7. Reattach negative and positive leads from battery. Turn fuel on.

IMPORTANT: Technical Support

For answers to questions regarding assembly or trouble shooting Riva Performance Products contact:
RIVA Tech Line at (954) 247-0705, online at tech_support@rivayamaha.com or you're local RIVA Dealer.

RIVA 90-day Limited Warranty

RIVA Extended Steering Nozzles carry a 90-day limited warranty to the original purchaser. They are warranted to be free of defects in materials and workmanship under normal use and service. Customer modified components will be void of warranty. This warranty is limited to defects in the primary aluminum components only. Finish and wear marks in or on steering nozzle are not covered under this warranty.

Riva's liability is expressly limited to the repair or replacement of the steering nozzle. Riva agrees to repair or at Riva's option, replace any defective unit without charge, if product is returned to Riva freight prepaid within the warranty period. Any equipment returned which, in Riva's opinion, has been subjected to misuse, abuse, or accident shall not be covered by this warranty.

Riva shall have no liability for special, incidental or consequential damages or injury to persons or property from any cause arising from the sale, installation or use of this product.

No other warranty, express or implied, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose, applies. Various states do not allow for the limitation of incidental or consequential damages and therefore the above exclusion or limitation may not apply to you.

Warranty does not include the expenses related to freight or transportation of parts or compensation for any inconvenience or loss of use while being repaired. A copy of the original invoice must accompany all warranty claims.

Warranted replacement parts will be returned freight collect.

Remember the water belongs to everyone! Please ride responsibly!