



RIVA High Performance Valve Set

The following specifications are provided as a guide only. We strongly recommend that only an experienced machinist prepare and install these valves. Failure to properly prep and install these valves falls solely on the end user. Due to the nature of performance applications these valves are sold without any express warranty or any implied warranty of merchantability or fitness for a particular purpose. RIVA Racing shall not, under any circumstances, be liable for any special, incidental or consequential damages, including, but not limited to damage, or loss of profits or revenue, cost of purchased or replacement goods, or claims of customers of the purchaser, which may arise and/or result from sale, installation or use of these valves. Installation will adversely affect the vehicle manufacturer's warranty coverage.

VALVE SEAT ANGLE -

All RIVA High Performance Valves (intake & exhaust; standard & oversized) are machined with a 45-degree seat angle. Refer to your OEM Service Manual for tolerance and specification information.

INSTALLATION -

Refer to the 'Engine Top End' section of your OEM Service Manual. It will be necessary to verify valve clearance.

Technical Support

For answers to questions regarding installation or trouble shooting RIVA Performance Products contact: RIVA Technical Support directly at (954) 247-0705 or by e-mail at tech_support@rivaracing.com.